


Indoor Wireless Night Vision Camera (ADC-V521IR)

Required Items for Installation:

- ADC-V521IR camera (included)
- The camera's mini-USB to Ethernet cable (included)
- Broadband (Cable, DSL, or Fiber Optic) Internet connection with Wi-Fi router
- A Wi-Fi enabled computer, tablet or smartphone
- An Ethernet / Cat5 cable
- Login/Password for the customer's Alarm.com account
- The case-sensitive Wi-Fi SSID (wireless network name) and the network password



Button Presses:

- Press and hold the WPS button until the LED flashes **blue**, for WPS learn in mode
- Press and hold the WPS button until the LED flashes **red/green**, to reset the camera

Install the Camera(s):

1. Connect the camera's mini-USB to Ethernet cord (camera dongle) into the back of the camera.
2. Connect the camera to the router with an Ethernet cord.
3. Plug in the camera's AC adapter and plug it into a non-switched outlet
4. Wait for the camera LED to turn solid green
5. Either use Mobile tech to install the camera **OR** open a browser and type in: **www.Alarm.com/AddCamera**
6. Select the camera from the list, or enter the camera's MAC Address (found on camera label and camera box) into the search field to begin the installation

Troubleshooting:

- If you run into issues with camera connectivity our installation, try power cycling the camera
- If issues persist, try resetting the camera to factory defaults by holding the reset button on the back of the camera until the LED flashes red and green, then try again

	LED Status	Description
Install	All off	Power off
	Blinking Red	Power on, system booting
	Green blink every second	Local network connection with local IP address
	Solid Green	Full internet connection with Alarm.com IP
	Blinking Blue	WPS learn-in mode
	Blinking White	Wi-Fi access point mode
Trouble Conditions	Solid Red	No local or Internet connection
	Red blink every 0.15 second + Green blink every 0.15 second	Restoring factory default settings
Factory Reset		

Questions?

Contact your security dealer with questions or issues.
If you are a security dealer, find your Dealer Support contact number at the following website www.alarm.com/dealersupport

EZ.INSTALL™